**Panasonic**
ideas for life

How to perform the factory reset (TGP500/550)

1. Connect to the Web UI
   a. Connect the Phone and a PC to the network
   b. Check the IP address of the phone using a handset.
      [Menu]->[IP Service]->[Network Setting]->[IP Settings]
   c. Enable the phone's Web UI using a handset
      [Menu]->[IP Service]->[Network Setting]->[Embedded Web]->[On]->[Save]
   d. Enter the IP address in a PC's Web Browser.
      example: Enter "http://192.168.1.68" in the address bar of Internet Explorer
   e. Enter Authentication ID and password
      ID:customerserviceid
      Password:cspass
   f. Now you can upload new Firmware into the phone using Web browser.

   Note: The phone's http server port will automatically close after idle time of 30 minutes.

2. Factory Reset
   a. Move to Maintenance - Reset to Defaults screen.
   b. Click [Reset to Factory Defaults]
   c. Please wait.
      The Base unit will reboot automatically.

Panasonic

KX-TGP550T04   Status   Maintenance

Step 2-1

Reset to Defaults

Web Port Close

Maintenance
Test Mode Setting
Local Firmware Update
Reset to Defaults
Restart

Reset Web Data
The Web data for this unit will be reset to its default values when you click [Reset Web Settings].

Reset Web Settings

Step 2-1

Reset to Factory Defaults
The following settings will be reset to their default values when you click [Reset to Factory Defaults].

Step 2-2

Reset to Factory Defaults

<NOTE>
Only the data of Base unit is removed.
The phonebook, redial, etc of a cordless handset are not removed.